PARTS LIST

Refer to the Exploded View Drawing for the location of parts listed below

ITEM	DESCRIPTION	ITEM	DESCRIPTION
1	SCREW	36	TRIGGER SPRING
2	BUSHING	37	SPRING PIN
3	EXHAUST COVER	38	TRIGGER
4	WASHER	39	TRIGGER
5	SCREW	40	WASHER
6	WASHER	41	SLEEVE
7	CYLINDER CAP	42	LATCH ASSEMBLY
8	GASKET	43	SPRING PIN
9	VALVE SEAL	44	PLATE
10	SPRING	45	SPRING PIN
11	O-RING	46	SCREW
12	O-RING	47	FRONT PLATE
13	VALVE	48	SCREW
14	O-RING	49	DRIVE GUIDE
15	STOPPED WASHER	50	PIN
16	COLLAR	51	MOVABLE MAGAZINE
17	O-RING	52	FEEDER SHOE
18	O-RING	52A	FEEDER SET
19	PISTON ASSEMBLY	53	SPRING
20	CYLINDER	54	RAIL
21	O-RING	54A	PIN
21A	O-RING	55	FIXED MAGAZINE
22	BUMPER	56	SCREW
23	BODY	57	STOPPED PLATE
24	JOINT GUIDE	58	LOCK
25	SPRING PIN	59	SPRING
26	SAFE GUIDE	60	SCREW
27	SPRING	61	BUSHING
28	SAFE BRACKET A	62	JOINT GUIDE
28A	SAFE BRACKET B	63	NUT
28B	SAFE BRACKET C	64	SUPPORT
29	SEAL	65	WASHER
30	TRIGGER VALVE HEAD	66	SCREW
31	SPRING	67	NUT
32	TRIGGER VALVE STEM	68	SOFT GRIP SLEEVE
32A	O-RING	69	O-RING
33	O-RING	70	END CAP
34	TRIGGER VALVE GUIDE	71	AIR PLUG
35	SPRING		

OPERATING INSTRUCTIONS

AIR NAILER

MODEL: F50F

SENCO®

Rendimiento. Poder.
Productividad.™

CONTENTS

SUMMARY ---------- 1

SPECIFICATIONS ---------- 1

SAFETY WARNINGS & CAUTIONS ---------- 1

UNPACKING ---------- 2

SETTING ---------- 2

CONNECTING THE TOOL TO AN AIR SUPPLY ---------- 3

LOADING THE FASTENERS ---------- 3

OPERATING THE TOOL ---------- 3

REGULAR MAINTENANCE ---------- 3

TROUBLE SHOOTING ---------- 4

EXPLODED VIEW DRAWING ---------- 5

PARTS LIST ---------- 6

EXPLODED VIEW DRAWING

